User Manual

Linear Opal series


Please read this manual before installation and keep it for future reference.

WARNING.

- 1. The safety of this lighting fixture is guaranteed only if you comply with these instructions.
- 2. Don't connect these lights to the mains supply directly, and please use the specific proper driver with specific input voltage.
- 3. Please, disconnect the power before installation, repair or replacement.
- 4. Use the lights in the proper application places as to avoid the lights be broken.

5.Do not locate fixtures in low areas where water will collect.

6.If any questions on this instruction, please consult a professional qualified technicians.



■Instructions of installation.

1. Ensure mains supply is switched off during the whole installation period.

Dug a hole according to the dimension of the mounting sleeve and below drawing "1", also make the tube for the cable in.


Put a layer of gravel and sand at the bottom of the hole. This to obtain a good drainage of the underground light.

Place the mounting box in the desired position ,then fix it with the concrete.


2.Remove the sealing cover with a screw driver after the concrete is dried.

3.Use the IP67 /IP68 waterproof connector to connect the LED linear light to the driver's wires that's with specific voltage output . Push the fixture into the mounting box.

4. Ensure everything is installed very well, and then turn on the power for the wall washer application.



Take out the linear light fixture with the provided tools when repairing or replacing fixtures.



<u>_____</u>Warning.

The non-professionals can not disassemble or repair the fixture. We keep the right to refuse the replacement or repairing of the fixtures that have been disassembled or repaired personally.