




Balloon Pump **SPORTS MATE P400**

Read all instructions and safety warnings before use.
If you have questions or comments, contact us.

(1)877-838-0209 Mon-Fri 8AM-5PM(PST)
Support@etenwolf.com

Register at <http://www.etenwolf.com>
to receive a 1-year extended warranty.

Manufacturer: Mozhen Technology (Shenzhen) Co., Ltd
CN-503, Floor 5, Building 4, Tianan Yungu Industrial Park Phase II,
Gangtou Community, Bantian Street, Longgang District, Shenzhen
(1)877-838-0209 Mon-Fri 8AM-5PM(PST)
support@etenwolf.com
www.etenwolf.com
www.facebook.com/etenwolf
Made in P.R.C



SUCCESS COURIER SL
CALLE RIO TORMES NUM.1, PLANTA 1, DERECHA,
OFICINA 3, Fuenlabrada, Madrid, 28947 Spain

OST_EU_20230616000062 successservice2@hotmail.com



1. IMPORTANT

- 1) Power supply must be AC 100 — 120V.
- 2) This is a high—volume pump. Please use this pump continuously no more than 2 hours, otherwise, it can overheat and damage the pump.
- 3) Keep the pump out of the reach of children.
- 4) Do not obstruct the inflation port & blowhole and keep them ventilated all the time.

2.WARNING


- 1) Never Leave pump unattended while the pump is in use.
- 2) Do not keep/use the pump in wet condition.
- 3) Never allow sands, small rocks , etc. to be sucked into inflation port & blowhole when using the pump.
- 4) Never look inside or point the inflation port & blowhole towards your eyes when the Pump is working.
- 5) Never attempt to put hand or fingers into the inflation port & blowhole at any time.

Remarks :


- The symbol “Auto” switch is suitable for inflating many balloons continuously, and the symbol “Touch-on” switch is suitable for single or few balloons.
- Open the cover of the storage cable before use, takes out the cable and close the cover ,connect plug to 110V-120V AC socket.

PRODUCT OVERVIEW

- 1 Power Switch —Auto, Off, Touch-on
- 2 Inflation Nozzle
- 3 Adapter for Foil balloon
- 4 Adapter for Round balloon(Under 12 inches)
- 5 Cable Storage
- 6 Power Plug(Kind prevail)




3.DIFFERENT BALLOONS INFLATING




Use adapter ④ for round balloons under 12 inches. For better inflate the balloon, the two adapters ④ must be installed clockwise before use.

Note: Choose ① Auto or Touch-on switch.




Use the nozzle ② for inflating round balloons over 12 inches. **Note:** choose ① Auto or Touch-on switch.




Use the adapter ③ for inflating foil balloons

Note: Choose ① Auto or Touch-on switch.


4.TO INFLATE BALLOONS




1. Pinch two sides of mouth of balloon with your fingers.



2. Wrap the mouth of the balloon over the nozzle.



3. Inflate the balloon by pressing down on the inflation port.



4. Release the port when the balloon is the right size.