


尺寸:85*120mm




Thanks for buying the electronic piano
Our company with 15 years experience of developing,producing a series of productions,about the portable piano and roll up drum kit.This product is light and very portable,in order to have the best use of the product,please strictly follow the instructions and precautions in the manual.May you enjoy it.Thanks for your cooperation.

I.The feature of the product:

- 37/49 keys
- 7 tones and 8 demos
- Volume increase/decrease
- Record function
- Play/Stop function
- Demo function
- Sustain function
- Metronome function
- With built-in speaker
- Power supply:3*AAA battery

II.Explanation of function button:



1	Tone	Tone button	7	Sustain	Sustain button
2	REC	REC button	8	Demo	Demo button
3	►	Play/Stop button	9	Speaker	Speaker
4	Vol-	Vol decrease button	10	ON/OFF button	ON/OFF button
5	Vol+	Vol increase button	11		
6	Metronome icon	Metronome button	12		

III.Function description

- 1.Tone**
·With 7 tones
·Press "Tone"button can select the tone cyclically on state
- 2.Volume**
·Total 5 levels of volume
·The biggest level when open,press "Vol-" decrease,press "Vol+" increase
- 3.REC function**
·Press "REC" button start to record,re-press it stop recording
·Can record for 10 minutes,or record 400 notes
- 4.Demo function**
·With 8 demos,press "Demo"button,play the demo song,play the next one when re-press this button
·After the current demo song has finished playing,play next one automatically, can press "►||" this button stop playing
- 5.►|| selection button**
·When demo/metronome/REC is working,press "►||" this button to terminate the corresponding function,re-press will continue
- 6.Metronome function**
·Total 4 beats.Press "Metronome icon" button,you can hear the sound of metronome,re-press it to switch the next beat

- 7.Sustain function**
·Press "Sustain"button,when you play,will extend the sound,re-press it,will close this function
- 8.Sleeping function**
·The system automatically enters sleeping state without any operation for 60 seconds,press any keys to wake it up

Tone list

NO	Name
001	Piano
002	Harp
003	Organ
004	Tubular bells
005	Violin
006	String ensemble 1
007	Acoustic Guitar

Demo list

NO	Name
001	DO RE MI
002	If you are happy and you know it
003	Once I caught a finish alive
004	4 rain rain go away
005	Silent night
006	The wheels on the bus 1
007	Jingle bells
008	Childhood

- IV. Protection of roll up piano:**
1.Can use the cleanly towel to clean it
2.It should be rolled well after using.
3.Do not put the piano in hot and humid place.
- V. Rollup piano using details**
·You should take out the battery while not using piano,in order to avoid the damage cause by batteries leak.
·In order to make sure every function is available,please put the unexpected damage will happened.
·You should not roll too tight after using it,or the key function will affected and the products lifetime will reduce.
·Do not put piano in high temperature or drippy place.
·In order to protect piano function,please do not set piano in strong radio wave place
- VI. .Simple trouble shooting**
·If piano stops working or abnormal sound come out while using it may the battery run out,please change another new battery.
·If the sound is abnormal,may the key function is unavailable,please turn off the power ,restart the machine,then restore the original settings.